

OPERATING MANUAL

Torque Motors



Introduction

■ Before using the motor

Only qualified personnel of electrical and mechanical engineering should work with the product.

Use the product correctly after thoroughly reading the section "Safety precautions." In addition, be sure to observe the contents described in warning, caution, and note in this manual.

The product described in this manual has been designed and manufactured to be incorporated in general industrial equipment. Do not use for any other purpose. Oriental Motor Co., Ltd. is not responsible for any damage caused through failure to observe this warning.

If you have purchased a torque motor and power controller package, also refer to the operating manual for **TM Series**.

■ Standard and CE Marking

Motors described in this manual are recognized by UL under the UL and CSA standards, and conform to the China Compulsory Certification System (CCC System). The motors are also affixed the CE Marking under the Low Voltage Directive.

Model names, which conform to the standards, are the motor model names.

Standards

UL 1004-1, UL 1004-3, CSA C22.2 No.100, CSA C22.2 No.77, GB/T 12350

Standards File No.

UL File No.E64197, CQC

Applications for Standard

EN 60034-1, EN 60034-5, EN 60664-1, EN 60950-1

A Running Heating Test and a Locked-Rotor Test has been conducted with a aluminum radiation plate of size indicated below. For the motor with a gearhead, tests has been conducted with a gearhead instead of the radiation plate.

First number in motor name	Size [mm (in.)]	Thickness [mm (in.)]	Material
2	115 × 115 (4.53 × 4.53)	5 (0.20)	Aluminum
3	125 × 125 (4.92 × 4.92)		
4	135 × 135 (5.31 × 5.31)		
5	165 × 165 (6.50 × 6.50)		

Installation conditions

Overvoltage category II, Pollution degree 2, Class I equipment (For EN Standards)
When the machinery to which the motor is mounted requires overvoltage category III and pollution degree 3 specifications, install the motor in a cabinet that comply with IP54 and connect to power supply via an isolation transformer.

Standards for accessories

Capacitor: UL File No.E83671 (CYWT2),
VDE License Nos.112847 (capacitors with a rated voltage of 250 VAC),
114747 (capacitors with a rated voltage of 450 VAC)

Capacitor cap: UL File No.E56078 (YDTU2)

■ RoHS Directive

The products do not contain the substances exceeding the restriction values of RoHS Directive (2011/65/EU).

Thank you for purchasing an Oriental Motor product.

This Operating Manual describes product handling procedures and safety precautions.

- Please read it thoroughly to ensure safe operation.
- Always keep the manual where it is readily available.

Safety precautions

The precautions described below are intended to prevent danger or injury to the user and other personnel through safe, correct use of the product. Use the product only after carefully reading and fully understanding these instructions.

Warning	Handling the product without observing the instructions that accompany a "Warning" symbol may result in serious injury or death.
Caution	Handling the product without observing the instructions that accompany a "Caution" symbol may result in injury or property damage.
Note	The items under this heading contain important handling instructions that the user should observe to ensure safe use of the product.

Warning

- Do not use the product in explosive or corrosive environments, in the presence of flammable gases, locations subjected to splashing water, or near combustibles. Doing so may result in fire, electric shock or injury.
- Assign qualified personnel the task of installing, wiring, operating/controlling, inspecting and troubleshooting the product. Failure to do so may result in fire, electric shock or injury.
- Do not transport, install the product, perform connections or inspections when the power is on. Always turn the power off before carrying out these operations. Failure to do so may result in electric shock.
- Turn off the power in the event the overheat protection device (thermal protector) is triggered. Failure to do so may result in injury or damage to equipment, since the motor will start abruptly when the overheat protection device (thermal protector) is automatically reset.
- The motor is Class I equipment. Install the motor so as to avoid contact with hands, or ground it to prevent the risk of electric shock.
- Install the motor in an enclosure in order to prevent electric shock or injury.
- Keep the input-power voltage within the specification to avoid fire and electric shock.
- Connect the cables securely according to the wiring diagram in order to prevent fire and electric shock.
- Do not forcibly bend, pull or pinch the lead wires. Doing so may result in fire and electric shock.
- Be sure to insulate the connection terminal of the capacitor. Failure to do so may result in electric shock.
- Turn off the power in the event of a power failure, or the motor will suddenly start when the power is restored and may cause injury or damage to equipment.
- Do not touch the connection terminal of the capacitor immediately after the power is turned off (for a period of 30 seconds). The residual voltage may cause electric shock.
- Do not disassemble or modify the motor. This may cause electric shock or injury.

Caution

- Do not use the motor beyond its specifications, or electric shock, injury or damage to equipment may result.
- Do not touch the motor during operation or immediately after stopping. The surface is hot and may cause a skin burn(s).
- Do not hold the motor output shaft or motor lead wires. This may cause injury.
- Keep the area around the motor free of combustible materials in order to prevent fire or a skin burn(s).
- To prevent the risk of damage to equipment, leave nothing around the motor that would obstruct ventilation.
- To prevent bodily injury, do not touch the rotating parts (output shaft) of the motor during operation.
- Immediately when trouble has occurred, stop running and turn off the power. Failure to do so may result in fire, electric shock or injury.

- The motor surface temperature may exceed 70 °C (158 °F) even under normal operating conditions. If the operator is allowed to approach a running motor, attach a warning label as shown in the figure in a conspicuous position. Failure to do so may result in skin burn(s).



Warning label

- Dispose the product correctly in accordance with laws and regulations, or instructions of local governments.

Preparation

■ Checking the product

Verify that the items listed below are included. Report any missing or damaged items to the branch or sales office from which you purchased the product.

- Motor 1 unit
- Capacitor 1 piece
- Capacitor cap 1 piece
- Operating manual (this manual) 1 copy
- Mounting screw set 1 set (combination type only)
(Mounting screws, hexagonal nuts, washers, spring washers 4 pieces, each, parallel key 1 piece *)

* The mounting screw set is not supplied with motors having no key grooves on the output shaft.

■ Checking the model name

Check the model number against the number indicated on the product.

Combination type, Pinion shaft type

Model	Motor model	Capacitor model	Gearhead model*
2TK3GN-AW2J	2TK3GN-AW2	CH70CFAUL2	2GN□S
2TK3GN-AW2U		CH60CFAUL2	
2TK3GN-CW2J	2TK3GN-CW2	CH18BFAUL	
2TK3GN-CW2E		CH15BFAUL	
3TK6GN-AW2J	3TK6GN-AW2	CH110CFAUL2	3GN□S
3TK6GN-AW2U		CH90CFAUL2	
3TK6GN-CW2J	3TK6GN-CW2	CH30BFAUL	
3TK6GN-CW2E		CH25BFAUL	
4TK10GN-AW2J	4TK10GN-AW2	CH140CFAUL2	4GN□S
4TK10GN-AW2U		CH110CFAUL2	
4TK10GN-CW2J	4TK10GN-CW2	CH35BFAUL	
4TK10GN-CW2E		CH30BFAUL	
5TK20GN-AW2J	5TK20GN-AW2	CH180CFAUL2	5GN□S
5TK20GN-AW2U		CH140CFAUL2	
5TK20GN-CW2J	5TK20GN-CW2	CH45BFAUL	
5TK20GN-CW2E		CH40BFAUL	

* □ in the gearhead model name represents a number indicating to the gear ratio.

- With combination types, the motor comes preassembled with the gearhead. Pinion shaft type gearheads are sold separately.

Round shaft type

Model	Motor model	Capacitor model
2TK3A-AW2J	2TK3A-AW2	CH70CFAUL2
2TK3A-AW2U		CH60CFAUL2
2TK3A-CW2J	2TK3A-CW2	CH18BFAUL
2TK3A-CW2E		CH15BFAUL
3TK6A-AW2J	3TK6A-AW2	CH110CFAUL2
3TK6A-AW2U		CH90CFAUL2
3TK6A-CW2J	3TK6A-CW2	CH30BFAUL
3TK6A-CW2E		CH25BFAUL
4TK10A-AW2J	4TK10A-AW2	CH140CFAUL2
4TK10A-AW2U		CH110CFAUL2
4TK10A-CW2J	4TK10A-CW2	CH35BFAUL
4TK10A-CW2E		CH30BFAUL
5TK20A-AW2J	5TK20A-AW2	CH180CFAUL2
5TK20A-AW2U		CH140CFAUL2
5TK20A-CW2J	5TK20A-CW2	CH45BFAUL
5TK20A-CW2E		CH40BFAUL

Installation

■ Location for installation

The motor is designed and manufactured for installation in equipment. Install it in a well-ventilated location that provides easy access for inspection.

The location must also satisfy the following conditions:

- Inside an enclosure that is installed indoors (provide vent holes)
- Operating ambient temperature
 - 10 to +40 °C (+14 to +104 °F) (non-freezing)
 - 10 to +50 °C (+14 to +122 °F) for 100/200 V
- Operating ambient humidity 85% or less (non-condensing)
- Area that is free of explosive atmosphere or toxic gas (such as sulfuric gas) or liquid
- Area not exposed to direct sun
- Area free of excessive amount of dust, iron particles or the like
- Area not subject to splashing water (rain, water droplets), oil (oil droplets) or other liquids
- Area free of excessive salt
- Area not subject to continuous vibration or excessive shocks
- Area free of excessive electromagnetic noise (from welders, power machinery, etc.)
- Area free of radioactive materials, magnetic fields or vacuum
- 1000 m or less above sea level

Note


On rare occasions, grease may ooze out from the gearhead. If there is a concern over possible environmental damage resulting from the leakage of grease, provide an oil tray or similar oil catching mechanism in order not to cause a secondary damage. Grease leakage may lead to problems in the customer's equipment or products.

■ How to install the motor

● Combination type

Drill holes on the mounting plate and fix the motor and gearhead on the plate using four screws (supplied).


Pay attention not to create a gap between the motor/gearhead assembly and the installation surface.



● Pinion shaft type

Drill holes on the mounting plate and fix the motor and gearhead on the plate using screws supplied with the gearhead. Be careful there is no gap between the motor flange and the gearhead.

For details of installation, see the operating manual supplied with the gearhead, which is sold separately.




Note

Use the gearhead with pinion shaft which is identical with one of motor.

● Round shaft type

Drill holes on the mounting plate and fix the motor on the plate using screws, nuts, and washers (not supplied).

Be careful there is no gap between the motor installation surface and the bracket.



First number of motor model	Nominal diameter of screw	Tightening torque [N·m (lb-in)]
2	M4	2.0 (17.7)
3	M5	2.5 (22)
4	M5	2.5 (22)
5	M6	3.0 (26)


Note

Do not insert the motor into the mounting hole at an angle or force it in, as this may scratch the flange pilot section and damage the motor.

■ Attaching load

To shaft of the gearhead has been machined to an outer diameter tolerance of h7 and is provided with a key slot for connecting the transmission parts.


(The **2GN** type has a surface cut by milling.) When connecting the transmission parts, ensure that the shaft and parts have a clearance fit, and always fix the parallel key to the output shaft with a screw to prevent the parts from rattling or spinning.



Note Do not use excessive force, or hammer the transmission parts onto the gearhead shaft as damage may occur.

■ Mounting the capacitor

Before mounting the supplied capacitor, check that the capacitor's capacitance matches that stated on the motor's name plate. Mount the capacitor securely by using M4 screws (not provided).



Note


- Do not let the screw fastening torque exceed 1 N·m (8.8 lb-in) to prevent damage to the mounting foot.
- Mount capacitor at least 10 cm (3.94 in.) away from the motor. If it is located closer, the life of the capacitor will be shortened.

■ Removing/Installing the gearhead

See the following steps to replace the gearhead or to change the outlet position of the lead wires.


Removing the gearhead from the motor

Remove the hexagonal socket head screws (2 pieces) assembling the motor and gearhead and detach the motor from the gearhead.



Installing the gearhead to the motor

1. Keep the pilot sections of the motor and gearhead in parallel, and assemble the gearhead with the motor while slowly rotating it clockwise/counterclockwise. At this time, note so that the pinion of the motor output shaft does not hit the side panel or gears of the gearhead strongly.



Assemble the gearhead to the motor in a condition where the motor output shaft is in an upward direction.

2. Check no gaps remain between the motor and gearhead, and tighten them with hexagonal socket head screws (2 pieces).

After the motor and gearhead have been assembled, install the motor/gearhead assembly using mounting screws by referring to the explanation under "Combination type" on p.2

Note

- Do not forcibly assemble the motor and gearhead. Also, do not let metal objects or other foreign matters enter the gearhead. The pinion or gear of the motor output shaft may be damaged, resulting in noise or shorter service life.
- The hexagonal socket head screws used to assemble the motor and gearhead together only tentatively secure the two components. Always use the four supplied mounting screws when installing the motor/gearhead assembly.

Connection and operation

Insulate all the wire connections, such as the connection between the motor and the capacitor connection.

Ground the motor using a Protective Earth Terminal.

For details on connecting the motor and power controller, refer to the operating manual for **TM** Series.

Note

- Insulation class of this motor is B. Make sure that the motor case temperature does not exceed 90 °C (194 °F) during operation of the motor. Operation exceeding case temperature 90 °C (194 °F) may significantly deteriorate the coils and ball bearings of the motor and shorten the motor's life span. Motor case temperature can be measured by fixing a thermometer on the motor surface. It can also be measured using thermo tape or a thermocouple.
- To change rotation direction wait until the motor completely stops. Otherwise its direction may not change or may take much time to change.
- If the motor is to be used with AC voltage, connect the supplied capacitor. Keep the capacitor connected even after the motor has been started.

■ Rotating direction of the gearhead output shaft


The rotating direction of the gearhead output shaft may be opposite that of the motor shaft, depending on the gear ratio. Before performing wiring, be sure to check the rotating direction of the gearhead output shaft to be used and determine the desired direction of motor rotation.

Gearhead model	Gear ratio	
	Same as the rotating direction of motor shaft	Opposite the rotating direction of motor shaft
2GN□S, 3GN□S, 4GN□S, 5GN□S	3 to 18	25 to 36
	50 to 180	


■ Wiring diagram

The connection method will vary depending on the direction. The direction of motor rotation is as viewed from the side of the motor's output shaft. The motor rotates in a clockwise (CW) and counterclockwise (CCW) direction.

Clockwise



Counterclockwise




■ Capacitor connection

The capacitor internal wiring as follows:

Capacitor terminals are internally electrically connection in twos; A-B and C-D for easy connection. For easy to install terminals use 187 series FASTON terminals (TE Connectivity).


Use the supplied capacitor cap to insulate the capacitor terminal connection.



Note For lead wire connection, use one lead wire for each individual terminal.

■ Connecting Protective Earth Terminal

Ground the motor using the motor's Protective Earth Terminal (⊕).
 Applicable crimp terminal: Round crimp terminal with insulation cover
 Thread size of terminal: M4
 Tightening torque: 1.0 to 1.3 N·m (8.8 to 11.5 lb-in)
 Applicable lead wire: AWG18 (0.75 mm²) or thicker



Note Do not use screws other than the protective earth terminal screws attached on the product.

Time rating

The time rating will vary, depending on the impressed voltage.

Specification	Voltage	Rating
Single-phase 100 V specification	100 V	Five-minute
	50 V	Continuous
Single-phase 110/115 V specification	110/115 V	Five-minute
	60 V	Continuous
Single-phase 200 V specification	200 V	Five-minute
	100 V	Continuous
Single-phase 220/230 V specification	220/230 V	Five-minute
	115 V	Continuous

Continuous ratings: The motors can be operated continuously.
 Five-minute ratings: The motors can be operated continuously for five minutes.

Locked rotor burnout protection

This motor is equipped with the feature listed below to prevent the motor from burning out as a result of abnormal heating which may be caused by misapplication.

■ Thermal protection

“TP” is stamped on the motor nameplate. The motor has an “auto reset” type thermal protector built into its motor coil. When the motor reaches a predetermined temperature, the internal thermal protector is activated and the motor is stopped. Always turn the power off before performing inspections.

Thermal protector activation range:

Motor type	Power is turned off	Power is turned back
3 W	130±5 °C (266±9 °F)	90±15 °C (194±27 °F)
6 to 20 W	130±5 °C (266±9 °F)	82±15 °C (180±27 °F)

Troubleshooting

When the motor cannot be operated correctly, refer to the contents provided in this section and take appropriate action. If the problem persists, contact your nearest office.

Phenomena	Check items
Motor does not rotate or rotates slowly.	<ul style="list-style-type: none"> Check the power supply voltage. Connect the power supply and the motor correctly. Connect the supplied capacitor correctly. If terminal blocks or crimp terminals are used, check them for poor connection. Keep the load at or below the allowable value.
Motor sometimes rotates and stops.	<ul style="list-style-type: none"> Connect the power supply and the motor correctly. Connect the supplied capacitor correctly. If terminal blocks or crimp terminals are used, check them for poor connection.

Phenomena	Check items
The motor rotates in the direction opposite to the specified direction.	<ul style="list-style-type: none"> Connect correctly by referring to “Wiring diagram.” Connect the supplied capacitor correctly. The rotating direction of the motor output shaft may be different from that of the gearhead output shaft depending on the gear ratio of the gearhead. Refer to “Rotating direction of the gearhead output shaft” on p.3. The rotating direction is indicated as viewed from the motor output shaft. Check the reference direction.
Motor temperature abnormally high. [Motor case temperature exceeds 90 °C (194 °F).]	<ul style="list-style-type: none"> Check the power supply voltage. Is the motor constrained or used continuously at a voltage exceeding the rated continuous voltage? Connect the supplied capacitor correctly. Review the ventilation condition.
Noisy operation.	<ul style="list-style-type: none"> Assemble the motor and gearhead correctly by referring to the operating manual for the gearhead. Check if the gearhead has the same gear-tooth profile as the motor.

- Unauthorized reproduction or copying of all or part of this manual is prohibited.
- Oriental Motor shall not be liable whatsoever for any problems relating to industrial property rights arising from use of any information, circuit, equipment or device provided or referenced in this manual.
- Characteristics, specifications and dimensions are subject to change without notice.
- While we make every effort to offer accurate information in the manual, we welcome your input. Should you find unclear descriptions, errors or omissions, please contact the nearest office.
- Oriental motor** is a registered trademark or trademark of Oriental Motor Co., Ltd., in Japan and other countries.

© Copyright ORIENTAL MOTOR CO., LTD. 2008

Published in July 2017

• Please contact your nearest Oriental Motor office for further information.

ORIENTAL MOTOR U.S.A. CORP.
 Technical Support Tel:(800)468-3982
 8:30 A.M. to 5:00 P.M., P.S.T. (M-F)
 7:30 A.M. to 5:00 P.M., C.S.T. (M-F)
www.orientalmotor.com
 ORIENTAL MOTOR DO BRASIL LTDA.
 Tel:+55-11-3266-6018
www.orientalmotor.com.br
 ORIENTAL MOTOR (EUROPA) GmbH
 Schiessstraße 44, 40549 Düsseldorf, Germany
 Technical Support Tel:00 800/22 55 66 22
www.orientalmotor.de
 ORIENTAL MOTOR (UK) LTD.
 Tel:01256-347090
www.oriental-motor.co.uk
 ORIENTAL MOTOR (FRANCE) SARL
 Tel:01 47 86 97 50
www.orientalmotor.fr
 ORIENTAL MOTOR ITALIA s.r.l.
 Tel:02-93906346
www.orientalmotor.it
 ORIENTAL MOTOR CO., LTD.
 4-8-1Higashiueno,Taito-ku,Tokyo 110-8536
 Japan
 Tel:03-6744-0361
www.orientalmotor.co.jp

ORIENTAL MOTOR ASIA PACIFIC PTE. LTD.
 Singapore
 Tel:1800-8420280
www.orientalmotor.com.sg
 ORIENTAL MOTOR (MALAYSIA) SDN. BHD.
 Tel:1800-806161
www.orientalmotor.com.my
 ORIENTAL MOTOR (THAILAND) CO., LTD.
 Tel:1800-888-881
www.orientalmotor.co.th
 ORIENTAL MOTOR (INDIA) PVT. LTD.
 Tel:+91-80-41125586
www.orientalmotor.co.in
 TAIWAN ORIENTAL MOTOR CO., LTD.
 Tel:0800-060708
www.orientalmotor.com.tw
 SHANGHAI ORIENTAL MOTOR CO., LTD.
 Tel:400-820-6516
www.orientalmotor.com.cn
 INA ORIENTAL MOTOR CO., LTD.
 Korea
 Tel:080-777-2042
www.inaom.co.kr
 ORIENTAL MOTOR CO., LTD.
 Hong Kong Branch
 Tel:+852-2427-9800